

↑ **Fold under on dotted line to use template** ↑

Center Line

2 1/8"

If printing a PDF of this template ensure this distance is 2 1/8" and 4 1/8."

←  
If printing a PDF for this template, ensure printing is set to actual/full size.

After positioning the template insert a pencil thru center of circles and mark the cabinet or shelf. Remove template and drill two (2) 3/16" holes for the hardware.

4 1/8"

## UPPERSLIDE CABINET CADDY FULL SIZE INSTALLATION TEMPLATE

**NOTICE:** On models 101, 202, 404 - ensure there is at least 5 15/16" from either side of center line to any side obstructions before drilling cabinet.

5 15/16" Min.

5 15/16" Min.

303S - 4 5/16" Min.  
303M - 5 13/16" Min.  
303L - 7 5/16" Min.

**NOTICE:** On models 303Small, 303Medium, and 303Large - ensure there is at least 4 5/16", 5 13/16", and 7 5/16" respectively.

303S - 4 5/16" Min.  
303M - 5 13/16" Min.  
303L - 7 5/16" Min.

↓ **FRONT OF  
CABINET**

Center Line

↓ **FRONT OF  
CABINET**